


CHAPTER 6 LOWER UNIT

LOWER UNIT	6-1
REMOVING THE LOWER UNIT	6-1
REMOVING THE PROPELLER	6-3
CHECKING THE PROPELLER	6-3
INSTALLING THE PROPELLER	6-3
INSTALLING THE TRIM TAB	6-3
WATER PUMP	6-4
REMOVING THE WATER PUMP	6-4
CHECKING THE WATER PUMP HOUSING	6-5
CHECKING THE IMPELLER AND INSERT CARTRIDGE	6-5
CHECKING THE WOODRUFF KEY	6-5
INSTALLING THE IMPELLER AND WATER PUMP HOUSING	6-5
SHIFT ROD	6-6
REMOVING THE SHIFT ROD	6-6
PROPELLER SHAFT HOUSING	6-7
REMOVING THE PROPELLER SHAFT HOUSING	6-7
DISASSEMBLING THE PROPELLER SHAFT HOUSING	6-8
DISASSEMBLING THE PROPELLER SHAFT	6-9
REMOVING THE PROPELLER SHAFT HOUSING	6-10
DISASSEMBLING THE PROPELLER SHAFT HOUSING	6-10
CHECKING THE REVERSE GEAR	6-11
CHECKING THE BEARING	6-11
CHECKING THE PROPELLER SHAFT HOUSING	6-11
ASSEMBLING THE PROPELLER SHAFT HOUSING	6-12
CHECKING THE DOG CLUTCH	6-13
CHECKING THE PROPELLER SHAFT	6-13
CHECKING THE SHIFT PLUNGER	6-13
CHECKING THE SPRING	6-13
DRIVE SHAFT	6-14
REMOVING THE DRIVE SHAFT	6-14
REMOVING THE DRIVE SHAFT	6-15
REMOVING THE DRIVE SHAFT BEARING	6-15
DISASSEMBLING THE FORWARD GEAR	6-15
CHECKING THE PINION AND FORWARD GEAR	6-16
CHECKING THE DRIVE SHAFT	6-16
CHECKING THE BEARINGS	6-16
ASSEMBLING THE FORWARD GEAR	6-16
INSTALLING THE DRIVE SHAFT BEARING	6-16
INSTALLING THE DRIVE SHAFT	6-17


LOWER CASE	6-18
DISASSEMBLING THE LOWER CASE	6-18
CHECKING THE DRIVE SHAFT SLEEVE	6-19
CHECKING THE NEEDLE BEARING	6-20
ASSEMBLING THE LOWER CASE	6-20
SHIMMING	6-21
SELECTING THE PINION SHIMS	6-22
SELECTING THE FORWARD GEAR SHIMS	6-24
SELECTING THE REVERSE GEAR SHIMS	6-26
BACKLASH	6-28
MEASURING THE FORWARD GEAR BACKLASH	6-28
MEASURING THE REVERSE GEAR BACKLASH	6-29

**LOWER UNIT
REMOVING THE LOWER UNIT**




Step	Job/Part	Q'ty	Remarks
1	Cotter pin	1	Not reusable
2	Castle nut	1	
3	Washer	1	
4	Spacer	1	
5	Propeller	1	
6	Spacer	1	
7	Nut	1	
8	Shift connector	1	
9	Bolt (with washer)	1	
10	Trim tab	1	
11	Bolt	1	
12	Anode	1	
13	Screw	2	

Continued on next page.



Step	Job/Part	Q'ty	Remarks
14	Nut	2	
15	Water inlet cover 1	1	
16	Water inlet cover 2	1	
17	Gear oil level check screw	1	
18	Gasket	1	
19	Gear oil drain screw	1	
20	Gasket	1	
21	Bolt	4	
22	Lower unit	1	
23	Pin	2	



REMOVING THE PROPELLER

Remove:

- Propeller


⚠ WARNING

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

CHECKING THE PROPELLER

Check:

- Blades
- Splines
Bent/cracks/damage/wear → Replace.
- Bushing
Slippage → Replace.



INSTALLING THE PROPELLER

Install:


- Propeller

⚠ WARNING

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

NOTE:

If the groove in the propeller nut is not aligned with the cotter pin hole, tighten the nut further until they are aligned.



INSTALLING THE TRIM TAB


Install:

- Trim tab

NOTE:

- To ease installation, mark the original position of the trim tab.
- Steering load varies depending on the trim tab position as installed.

**WATER PUMP
REMOVING THE WATER PUMP**



Step	Job/Part	Q'ty	Remarks
1	Bolt	4	
2	Plate	1	
3	Water tube	1	
4	O-ring	1	Not reusable
5	O-ring	1	Not reusable
6	Water seal rubber	1	
7	Water pump housing	1	
8	Insert cartridge	1	
9	O-ring	1	Not reusable
10	Impeller	1	
11	Impeller plate	1	
12	Dowel pin	1	
13	Woodruff key	1	



CHECKING THE WATER PUMP HOUSING

Check:

- Water pump housing
Cracks/damage → Replace.

CHECKING THE IMPELLER AND INSERT CARTRIDGE



Check:

- Impeller
- Insert cartridge
Cracks/damage/wear → Replace.

CHECKING THE WOODRUFF KEY

Check:

- Woodruff key
Damage/wear → Replace.



INSTALLING THE IMPELLER AND WATER PUMP HOUSING


Install:

- Impeller ①
- Insert cartridge ②
- Water pump housing ③


NOTE:

- When installing the insert cartridge ②, align its projection with the hole in the water pump housing ③.
- When installing the water pump housing, turn the drive shaft clockwise.
- Apply Yamaha grease A (water resistant grease) on the impeller ①, the insert cartridge ②, and the water pump housing ③.

SHIFT ROD
REMOVING THE SHIFT ROD




Step	Job/Part	Q'ty	Remarks
	Impeller plate		Refer to "WATER PUMP" on page 6-4.
1	Bolt	2	
2	Bracket	1	
3	Plate	1	
4	O-ring	1	Not reusable
5	Oil seal housing	1	
6	Lower casing packing	1	Not reusable
7	Dowel pin	1	
8	Shift rod	1	
9	Rubber seal	1	
10	Oil seal	2	



PROPELLER SHAFT HOUSING


REMOVING THE PROPELLER SHAFT HOUSING



Step	Job/Part	Q'ty	Remarks
	Gear oil		Refer to "CHANGING AND CHECKING THE GEAR OIL" on page 3-20.
	Shift rod assembly		Refer to "SHIFT ROD" on page 6-6.
1	Bolt	2	
2	Propeller shaft housing	1	
3	Washer	1	
4	Propeller shaft	1	




DISASSEMBLING THE PROPELLER SHAFT HOUSING





Step	Job/Part	Q'ty	Remarks
1	O-ring	1	Not reusable
2	O-ring	2	Not reusable
3	Reverse gear	1	
4	Reverse gear shim	*	
5	Ball bearing	1	
6	Oil seal	2	
7	Needle bearing	1	
8	Propeller shaft housing	1	
9	Washer	1	

* As required

DISASSEMBLING THE PROPELLER SHAFT



Step	Job/Part	Q'ty	Remarks
1	Shift plunger	1	
2	Cross pin ring	1	
3	Cross pin	1	
4	Spring	1	
5	Dog clutch	1	
6	Propeller shaft	1	




REMOVING THE PROPELLER SHAFT HOUSING

Remove:

- Propeller shaft housing



- Bearing housing puller claw ①**
90890-06564
- Stopper guide plate ②**
90890-06501
- Center bolt ③**
90890-06504




DISASSEMBLING THE PROPELLER SHAFT HOUSING



1. Remove:

- Reverse gear



- Bearing separator ①**
90890-06534
- Stopper guide plate ②**
90890-06501
- Stopper guide stand ③**
90890-06538
- Bearing puller ass'y ④**
90890-06535






2. Remove:
- Ball bearing

	Stopper guide plate ① 90890-06501
	Stopper guide stand ② 90890-06538
	Bearing puller ass'y ③ 90890-06535

NOTE: _____
Do not reuse the bearing. Always replace it with a new one.



3. Remove:
- Oil seal
 - Needle bearing

	Driver rod L3 ① 90890-06652
	Needle bearing attachment ② 90890-06615

CHECKING THE REVERSE GEAR


- Check:
- Teeth
 - Dogs
- Damage/wear → Replace.


CHECKING THE BEARING

- Check:
- Bearing
- Pitting/rumbling → Replace.

CHECKING THE PROPELLER SHAFT HOUSING

- Check:
- Propeller shaft housing
- Cracks/damage → Replace.






ASSEMBLING THE PROPELLER SHAFT HOUSING

1. Install:
 - Needle bearing

	Needle bearing position.....(a) 31.0 - 31.5 mm (1.22 - 1.24 in)
--	--

	Driver rod-SS.....(1) 90890-06604 Needle bearing attachment.....(2) 90890-06615 Bearing depth plate.....(3) 90890-06603
--	--

NOTE: _____
 Install the needle bearing with its manufacturer's marks (b) facing up. Apply Yamaha motor oil.







2. Install:
 - Oil seals

	Oil seal position.....(a) 6.0 - 6.5 mm (0.24 - 0.26 in)
--	--

	Driver rod L3.....(1) 90890-06652 Needle bearing attachment.....(2) 90890-06611
--	--

CAUTION: _____

It is essential that the oil seals are installed correctly (as shown in the illustration). If they are installed the wrong way round, oil or water will leak out.



3. Install:

- Reverse gear ①
- Reverse gear shim(s) ②
- Ball bearing ③
- Propeller shaft housing ④

NOTE:

- Before press-fitting the ball bearing, install the reverse gear shim(s).
- Install the ball bearing with its manufacturer's marks (a) facing the reverse gear.

CAUTION:

Place a suitable base under the gear to protect it from damages.

CHECKING THE DOG CLUTCH

Check:

- Dog clutch
Damage/wear → Replace.

CHECKING THE PROPELLER SHAFT

Check:

- Propeller shaft
Damage/wear → Replace.



**Maximum runout
0.1 mm (0.004 in)**

CHECKING THE SHIFT PLUNGER

Check:


- Shift plunger
Wear → Replace.

CHECKING THE SPRING


Check:

- Spring
Weak → Replace.

**DRIVE SHAFT
REMOVING THE DRIVE SHAFT**



Step	Job/Part	Q'ty	Remarks
	Propeller shaft housing		Refer to "PROPELLER SHAFT HOUSING" on page 6-7.
1	Pinion gear nut	1	
2	Pinion gear	1	
3	Drive shaft	1	
4	Forward gear	1	
5	Drive shaft bearing	1	



REMOVING THE DRIVE SHAFT


Remove:

- Pinion gear nut
- Drive shaft

	Drive shaft holder 3 ① 90890-06517
---	---

Removing Steps


- (1) Apply 12mm wrench on the pinion gear nut.
- (2) Support the lower case with rags to hold the wrench in position.
- (3) Turn the drive shaft holder ①.




REMOVING THE DRIVE SHAFT BEARING

Remove:

- Taper roller bearing

	Bearing inner race attachment ① 90890-06643
---	---



DISASSEMBLING THE FORWARD GEAR

Remove:

- Taper roller bearing ①
- Forward gear ②

	Bearing separator 90890-06534
---	--

CAUTION:


Place a suitable base on the gear axle to prevent damage to the top of the axle.



CHECKING THE PINION AND FORWARD GEAR

Check:

- Teeth
 - Dogs
- Damage/wear → Replace.




CHECKING THE DRIVE SHAFT

Check:

- Drive shaft
- Damage/wear → Replace.




**Maximum runout
0.5 mm (0.020 in)**



CHECKING THE BEARINGS

Check:

- Bearings
- Pitting/rumbling → Replace.




ASSEMBLING THE FORWARD GEAR

Install:

- Forward gear
- Taper roller bearing



**Bearing inner race attachment ①
90890-06644**




INSTALLING THE DRIVE SHAFT BEARING

Install:

- Drive shaft bearing




**Bearing inner race attachment ①
90890-06645**




INSTALLING THE DRIVE SHAFT

1. Install:
 - Forward gear
(with the tapered roller bearing)
 - Drive shaft
(with the tapered roller bearing)
 - Pinion gear

	Drive shaft holder 3 ① 90890-06517
---	---

2. Tighten:
 - Pinion gear nut

	Pinion gear nut 50 N·m (5.0 kgf·m, 37 ft·lb)
---	---




Tightening steps

- (1) Apply 12mm wrench on the pinion gear nut.
- (2) Support the lower case with rags to hold the wrench in position.
- (3) Turn the drive shaft holder ①.

NOTE: _____
Tighten the pinion gear nut with the same tools that were used for removal.


LOWER CASE

DISASSEMBLING THE LOWER CASE




Step	Job/Part	Q'ty	Remarks
1	Drive shaft bearing outer race	1	
2	Pinion gear shim	*	
3	Drive shaft sleeve	1	
4	Needle bearing	1	
5	Tapered roller bearing outer race	1	
6	Forward gear shim	*	

* As required





1. Remove:
 - Drive shaft bearing outer race
 - Pinion gear shim(s)

	Stopper guide plate① 90890-06501
	Bearing puller ass'y② 90890-06535
	Stopper guide stand③ 90890-06538




2. Remove:
 - Drive shaft needle bearing and sleeve

	Driver rod L3① 90890-06652
	Needle bearing attachment② 90890-06615




3. Remove:
 - Forward gear bearing outer race and shim(s)

	Stopper guide plate① 90890-06501
	Bearing puller ass'y② 90890-06535



CHECKING THE DRIVE SHAFT SLEEVE


- Check:
- Drive shaft sleeve
Damage/wear → Replace.



CHECKING THE NEEDLE BEARING

Check:

- Needle bearing
Pitting/rumbling → Replace.



ASSEMBLING THE LOWER CASE

1. Install:


- Forward gear shim(s) ①
- Tapered roller bearing outer race ②

	Bearing outer race attachment 90890-06622 Driver rod LL 90890-06605
--	--

2. Install:


- Drive shaft needle bearing

	Depth ^a 185.0 - 186.0 mm (7.28 - 7.32 in)
--	---



	Needle bearing attachment① 90890-06615 Driver rod SL② 90890-06602 Bearing depth plate③ 90890-06603
--	---

NOTE: _____
Install the drive shaft needle bearing with the manufacturer's marks facing up.



3. Install:


- Pinion gear shim(s) ^a
- Drive shaft bearing outer race ^b




	Driver rod LS① 90890-06606 Bearing outer race attachment....② 90890-06628
--	--

SHIMMING

NOTE:

- There is no need to select shims when reassembling with the original case and inner part(s).
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).





SELECTING THE PINION SHIMS

NOTE: _____
 Select the shim thickness (T3) by using the specified measurement(s) and the calculation formula.

Select:

- Shim thickness (T3)

Selecting steps

(1) Install the pinion height gauge, drive shaft and bearing (with bearing race).

	Pinion height gauge ① 90890-06702
	Drive shaft holder 3 ② 90890-06517


NOTE: _____

- Attach the pinion height gauge to the drive shaft so that the shaft is at the center of the hole.
- After the wing nuts contact the fixing plate, tighten them another 1/4 of a turn.

(2) Install the pinion gear and pinion gear nut.


	Pinion gear nut 50 N•m (5.0 kgf•m, 37 ft•lb)
---	---

(3) Measure (M).

	Digital caliper 90890-06704
---	--

NOTE: _____

- Measure the clearance between the pinion height gauge and the pinion, as shown.
- Perform the same measurement at three points on the pinion.
- Find the average of the measurements (M).
- When using the digital caliper, be sure to place it at right angles to the pinion. Otherwise, measurement will be incorrect.



(4) Calculate the pinion gear shim thickness (T3).



Pinion gear shim thickness (T3) =
M - 27 mm - P/100 mm

NOTE:

- "P" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01 mm units. If the "P" mark is missing or unreadable, assume a "P" value of "0", and check the backlash when the unit is assembled.
- If the "P" mark is negative (-), then add the "P" value to the measurement.

Example:

If M is "28.30 mm" and "P" is "+5", then:

$$T3 = 28.30 \text{ mm} - 27 \text{ mm} - (+5)/100 \text{ mm}$$

$$= 1.3 \text{ mm} - 0.05 \text{ mm}$$

$$= 1.25 \text{ mm (0.049 in)}$$

If M is "28.24 mm" and "P" is "-3", then:

$$T3 = 28.24 \text{ mm} - 27 \text{ mm} - (-3)/100 \text{ mm}$$

$$= 1.24 \text{ mm} + 0.03 \text{ mm}$$


$$= 1.27 \text{ mm (0.05 in)}$$

(5) Select the pinion gear shim(s) (T3).

Calculated numeral at 1/100th place		Using shim
more than	or less	
1.10	1.20	1.2
1.20	1.30	1.3
1.30	1.40	1.4
1.40	1.50	1.5
1.50	1.60	1.6
1.60	1.70	0.7, 1.0
1.70	1.83	0.7, 1.1



Available shim thickness
0.7, 1.0, 1.1, 1.2, 1.3, 1.4, 1.5 and 1.6 mm



SELECTING THE FORWARD GEAR SHIMS

NOTE:


Select the shim thickness (T1) by using the specified measurement(s) and the calculation formula.

Select:

- Shim thickness (T1)

Selecting steps


(1) Measure (M).




	Shimming plate ① 90890-06701
	Digital caliper ② 90890-06704


NOTE:

- Turn the tapered roller bearing outer race two or three times so that the rollers seat. Then, measure the height of the bearing, as shown.
- Perform the same measurement at three points on the tapered roller bearing outer race.
- Find the average of the measurements (M).
- When using the digital caliper, be sure to place it at right angles to the shimming plate. Otherwise, measurement will be incorrect.



(2) Calculate the forward gear shim thickness (T1).



	Forward gear shim thickness (T1) = 17.5 mm + F/100 mm - M
---	--

NOTE:

- "F" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01 mm units. If the "F" mark is missing or unreadable, assume an "F" value of "0", and check the backlash when the unit is assembled.
- If the "F" mark is negative (-), then subtract the "F" value from the measurement.

Example:


If M is "16.25 mm" and "F" is "+4", then:


$$\begin{aligned}
 T1 &= 17.5 \text{ mm} + (+4)/100 \text{ mm} - 16.25 \text{ mm} \\
 &= 17.5 \text{ mm} + 0.04 \text{ mm} - 16.25 \text{ mm} \\
 &= 1.29 \text{ mm} (0.051 \text{ in})
 \end{aligned}$$

If M is "16.26 mm" and "F" is "-3", then:

$$\begin{aligned}
 T1 &= 17.5 \text{ mm} + (-3)/100 \text{ mm} - 16.26 \text{ mm} \\
 &= 17.5 \text{ mm} - 0.03 \text{ mm} - 16.26 \text{ mm} \\
 &= 1.21 \text{ mm} (0.048 \text{ in})
 \end{aligned}$$

(3) Select the forward gear shim(s) (T1).

Calculated numeral at 1/100th place		Using shim
more than	or less	
1.00	1.10	1.0
1.10	1.20	1.1
1.20	1.30	1.2
1.30	1.40	1.3
1.40	1.50	1.4
 Available shim thickness 1.0, 1.1, 1.2, 1.3 and 1.4 mm		




SELECTING THE REVERSE GEAR SHIMS

NOTE: _____
 Select the shim thickness (T2) the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T2)

Selecting steps

(1) Measure (M2).





	Shimming plate ① 90890-06701
	Digital caliper ② 90890-06704

NOTE: _____

- Measure the height of the gear as shown.
- Perform the same measurement at three points on the gear.
- Find the average of the measurements (M2).
- When using the digital caliper, be sure to place it at right angles to the shimming plate. Otherwise, measurement will be incorrect.

(2) Calculate the reverse gear shim thickness (T2).



	Reverse gear shim thickness (T2) = 80 mm + R/100 - M2
---	---

NOTE: _____

- "R" is the deviation of the lower case dimension from standard. It is stamped on the anode mounting surface of the lower case in 0.01 mm units. If the "R" mark is missing or unreadable, assume a "R" value of "0", and check the backlash when the unit is assembled.
- If the "R" mark is negative (-), then subtract the "R" value from the measurement.



Example:


If M2 is "78.79 mm" and "R" is "+5", then:

$$\begin{aligned}
 T2 &= 80 \text{ mm} + (+5)/100 \text{ mm} - 78.79 \text{ mm} \\
 &= 80 \text{ mm} + 0.05 \text{ mm} - 78.79 \text{ mm} \\
 &= 1.26 \text{ mm (0.050 in)}
 \end{aligned}$$

If M2 is "78.75 mm" and "R" is "-3", then:

$$\begin{aligned}
 T2 &= 80 \text{ mm} + (-3)/100 \text{ mm} - 78.75 \text{ mm} \\
 &= 80 \text{ mm} - 0.03 \text{ mm} - 78.75 \text{ mm} \\
 &= 1.22 \text{ mm (0.048 in)}
 \end{aligned}$$

(3) Select the reverse gear shim(s) (T2).


Calculated numeral at 1/100th place		Using shim
more than	or less	
1.00	1.10	1.0
1.10	1.20	1.1
1.20	1.30	1.2
1.30	1.32	1.3
 Available shim thickness 1.0, 1.1, 1.2 and 1.3 mm		



BACKLASH

NOTE:

- Do not install the water pump components when measuring the backlash.
- Measure both the forward and reverse gear backlashes.
- If both the forward and reverse gear backlashes are larger than specification, the pinion gear may be too high.
- If both the forward and reverse gear backlashes are smaller than specification, the pinion gear may be too low.



MEASURING THE FORWARD GEAR BACKLASH



1. Measure:
 - Forward gear backlash
 Out of specification → Adjust.



Forward gear backlash
0.31 - 0.72 mm (0.012 - 0.028 in)

Measuring steps


- (1) Set the shift rod into the neutral position.
- (2) Install the propeller shaft housing puller so it pushes against the propeller shaft.



Bearing housing puller claw ①
90890-06564
Stopper guide plate..... ②
90890-06501
Center bolt..... ③
90890-06504



Center bolt
5 N·m (0.5 kgf·m, 3.7 ft·lb)



(3) Install the backlash indicator onto the drive shaft (16mm (0.63 in) diameter).

	Backlash indicator (4) 90890-06706
--	---

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	Magnet base plate (5) 90890-07003
	Dial gauge set (6) 90890-01252
	Magnet base (7) 90890-06705

(5) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

2. Adjust:

- Forward gear backlash
Remove or add shim(s).

	Forward gear backlash	Shim thickness
	Less than 0.31 mm (0.012 in)	To be decreased by $(0.52 - M) \times 0.49$
	More than 0.72 mm (0.028 in)	To be increased by $(M - 0.52) \times 0.49$
Available shim thickness: 1.0, 1.1, 1.2, 1.3 and 1.4 mm		




M : Measurement

MEASURING THE REVERSE GEAR BACKLASH

1. Measure:

- Reverse gear backlash
Out of specification → Adjust.

	Reverse gear backlash 0.93 - 1.65 mm (0.037 - 0.065 in)
--	--



Measuring steps

- (1) Set the shift rod into the neutral position.
- (2) Load the reverse gear by installing the propeller without the collar ①, and then tighten the propeller nut.



Propeller nut
5 N·m (0.5 kgf·m, 3.7 ft·lb)

- (3) Install the backlash indicator onto the drive shaft (16 mm (0.63 in) diameter).



Backlash indicator ②
90890-06706

- (4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.




Magnet base plate ③
90890-07003
Dial gauge set ④
90890-01252
Magnet base ⑤
90890-06705

- (5) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

2. Adjust:

- Reverse gear backlash
Remove or add shim(s).

 Reverse gear backlash	Shim thickness
Less than 0.93 mm (0.037 in)	To be decreased by $(1.29 - M) \times 0.49$
More than 1.65 mm (0.065 in)	To be increased by $(M - 1.29) \times 0.49$
Available shim thickness 1.0, 1.1, 1.2 and 1.3 mm	

M : Measurement